

## Achieve odourless and hassle-free urinals

### Directions for use

1. Take a scoop
2. Pour it into the urinal
3. Followed by half a cup of water
4. Let the bacteria get to work



### Dosing Instructions

**A standard dose is 25g**

#### Shock Phase:

For the first 4 weeks dose each urinal with 2 scoops, twice a week.

#### Maintenance Phase:

A 25g scoop, applied each week directly into the bowl, is all that is needed to maintain each urinal free of odours and blockages

